



Page

Table of Contents

2 - 8	<u>Bracket Kit</u>	Vehicle Specific Reference Guide
9	<u>Matrix</u>	Series Running boards
10	<u>E2</u>	Series Running boards
11	<u>SL</u>	Series Running Board
11	<u>Platinum</u>	Series Running Board
12	<u>Edge</u>	Series Running Board
12	<u>Factory Style</u>	Series Running Board
13	<u>UNI. II.</u>	Series Board Lighted & Non-Lighted
13	<u>UNI. I.</u>	Series Board Lighted & Non-Lighted
14	<u>X-Treme I.</u>	Series Board Lighted & Non-Lighted
14	<u>X-Treme II.</u>	Series Board Lighted & Non-Lighted
14	<u>Custom</u>	Series Running Boards Toyota & Lexus
14	<u>Front Valances</u>	Truck & SUV Paintable
15	<u>Fender Flares</u>	Truck & SUV Paintable
16	<u>Replacement</u>	Parts and Accessories

[www.atsdesign.com](http://www.atsdesign.com)

866.213.2873

Revised 03/01/2010



## Vehicle Specific Bracket Kit & Part # Reference

Vehicle Description		Running Board Reference Fitment									
<b>Acura</b>		<b>BRK KIT</b>	<b>MX</b>	<b>E2</b>	<b>SL</b>	<b>PLT</b>	<b>EDGE</b>	<b>UNI</b>	<b>UNI-II</b>	<b>X</b>	<b>X-II</b>
YEAR		C810	C110	C310	C410	C510	C610	C810	C710	C910	C910
2002-06	MDX (need to remove mud flap)	BRK-81	CU70	CU70	CU70	CU70	CU70	CU69	CU70	CU69	CU71
2008-09	RDX	BRK-131	CU70	CU70	CU70	CU70	CU70	CU69	CU70	CU69	N/A
2008-10	MDX	BRK-132	CU70	CU70	CU70	CU70	CU70	CU69	CU70	CU69	N/A
<b>Buick</b>		<b>BRK KIT</b>	<b>MX</b>	<b>E2</b>	<b>SL</b>	<b>PLT</b>	<b>EDGE</b>	<b>UNI</b>	<b>UNI-II</b>	<b>X</b>	<b>X-II</b>
YEAR		C810	C110	C310	C410	C510	C610	C810	C710	C910	C910
2003-07	Rainer	BRK-10	CU70	CU70	CU70	CU70	CU70	CU70	CU70	CU77	CU71
2005-10	Terraza Van	BRK-99	CU86	CU86	CU86	CU86	CU86	CU86	N/A	N/A	N/A
<b>Chevrolet</b>		<b>BRK KIT</b>	<b>MX</b>	<b>E2</b>	<b>SL</b>	<b>PLT</b>	<b>EDGE</b>	<b>UNI</b>	<b>UNI-II</b>	<b>X</b>	<b>X-II</b>
YEAR		C810	C110	C310	C410	C510	C610	C810	C710	C910	C910
1988-04	Astro Van (need to move AC lines)	BRK-20	CU80	CU80	CU80	CU80	CU80	CU80	CU80	N/A	N/A
2003-05	Astro Van W/cladding (need to move AC lines)	BRK-20	CU70	CU70	CU70	CU70	CU70	CU70	CU70	CU70	N/A
2002-04	Avalanche W/cladding (Unlighted)	BRK-09	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU84	CU80
2003-04	Avalanche	BRK-09	CU86	CU86	CU86	CU86	CU86	CU86	CU90	N/A	CU90
2005-10	Avalanche	BRK-119A	CU90	CU90	CU90	CU90	CU90	CU90	CU90	N/A	CU90
1992-99	CK Classic Crew Cab (90" board extends into bed)	BRK-15	CU86	CU86	CU86	CU86	CU86	CU86	CU90	N/A	CU90
1988-99	Classic EXT.Cab 1500/2500	BRK-11	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU77	CU80
2005-09	Equinox	BRK-62	CU80	CU80	CU80	CU80	CU80	CU80	CU80	N/A	N/A
2010-11	Equinox <b>**NEW APPLICATION**</b>	BRK-160	CU70	CU70	CU70	CU70	CU70	CU70	CU70	N/A	N/A
1999-06	1500 STD.Cab (No SS model)	BRK-16S	CU54	N/A	CU54	CU54	CU54	CU54	CU54	CU54	N/A
1999-06	HD1500/2500 EXT.Cab (No SS model)	BRK-16	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU77	CU80
2001-06	HD2500 Crew Cab (90" board extends into bed)	BRK-17	CU86	CU86	CU86	CU86	CU86	CU86	N/A	N/A	N/A
2004-06	HD 1500 Crew Cab (90" board extends into bed)	BRK-17A	CU86	CU86	CU86	CU86	CU86	CU86	N/A	N/A	N/A
1999-06	Silverado EXT. Cab (No SS model)	BRK-16	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU77	CU80
2007-10	Silverado EXT.Cab	BRK-130	CU80	CU80	CU80	CU80	CU80	CU80	CU80	N/A	CU80
2007-10	Silverado STD. Cab	BRK-130	CU54	N/A	CU54	CU54	CU54	CU54	CU54	CU54	N/A
2007-10	Silverado Crew Cab(90" board extends into bed)	BRK-126	CU86	CU86	CU86	CU86	CU86	CU86	N/A	N/A	N/A
1992-99	Suburban	BRK-15	CU90	CU90	CU90	CU90	CU90	CU90	CU90	N/A	CU90
2000-04	Tahoe 4-Door	BRK-18	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU77	CU80
2005-10	Tahoe 4-Door	BRK-119	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU77	CU80
2001-10	Trailblazer	BRK-10	CU70	CU70	CU70	CU70	CU70	CU70	N/A	CU77	CU71
2000-04	Suburban	BRK-18	CU90	CU90	CU90	CU90	CU90	CU90	CU90	N/A	CU90
2005-10	Suburban	BRK-119A	CU90	CU90	CU90	CU90	CU90	CU90	CU90	N/A	CU90
1997-04	S10 Blazer 4-doors (N/A OEM cladding)	BRK-14	CU70	CU70	CU70	CU70	CU70	CU70	CU70	CU69	CU71



## Vehicle Specific Bracket Kit & Part # Reference

<i>Vehicle Description</i>		<i>Running Board Reference Fitment</i>									
<b>Chevrolet</b>		<b>BRK KIT</b>	<b>MX</b>	<b>E2</b>	<b>SL</b>	<b>PLT</b>	<b>EDGE</b>	<b>UNI</b>	<b>UNI-II</b>	<b>X</b>	<b>X-II</b>
<b>YEAR</b>		<b>C810</b>	<b>C110</b>	<b>C310</b>	<b>C410</b>	<b>C510</b>	<b>C610</b>	<b>C810</b>	<b>C710</b>	<b>C910</b>	<b>C910</b>
1998-04	S10 EXT. & Crew Cab	BRK-14	CU80	CU80	CU80	CU80	CU80	CU80	CU80	N/A	CU80
1998-04	S10 STD. Cab	BRK-14S	CU54	N/A	CU54	CU54	CU54	CU54	CU54	CU54	N/A
1996-99	Tahoe 4-Door	BRK-12	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU77	CU80
1996-99	Tahoe 2-Door	BRK-12	CU70	CU70	CU70	CU70	CU70	CU70	CU70	CU77	CU71
2002-07	TrailBlazer EXT.	BRK-70	CU90	CU90	CU90	CU90	CU90	CU90	CU90	N/A	CU90
2004-10	Colorado Crew Cab	BRK-92	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU77	CU80
2004-10	Colorado EXT. Cab	BRK-92	CU70	CU70	CU70	CU70	CU70	CU70	CU70	N/A	CU71
2004-10	Colorado STD. Cab	BRK-92S	CU54	N/A	CU54	CU54	CU54	CU54	CU54	CU54	N/A
2005-10	Uplander Van (Short wheel base only)	BRK-99	CU80	CU80	CU80	CU80	CU80	CU80	CU80	N/A	CU80
2005-10	Uplander Van (Long wheel base only)	BRK-99	CU86	CU86	CU86	CU86	CU86	CU86	N/A	N/A	N/A
<b>Chrysler</b>		<b>BRK KIT</b>	<b>MX</b>	<b>E2</b>	<b>SL</b>	<b>PLT</b>	<b>EDGE</b>	<b>UNI</b>	<b>UNI-II</b>	<b>X</b>	<b>X-II</b>
<b>YEAR</b>		<b>C810</b>	<b>110</b>	<b>C310</b>	<b>C410</b>	<b>C510</b>	<b>C610</b>	<b>C810</b>	<b>C710</b>	<b>C910</b>	<b>C910</b>
2006 -10	Aspen	BRK-93	CU80	CU80	CU80	CU80	CU80	CU80	CU80	N/A	CU80
<b>Dodge</b>		<b>BRK KIT</b>	<b>MX</b>	<b>E2</b>	<b>SL</b>	<b>PLT</b>	<b>EDGE</b>	<b>UNI</b>	<b>UNI-II</b>	<b>X</b>	<b>X-II</b>
<b>YEAR</b>		<b>C810</b>	<b>C110</b>	<b>C310</b>	<b>C410</b>	<b>C510</b>	<b>C610</b>	<b>C810</b>	<b>C710</b>	<b>C910</b>	<b>C910</b>
1998-04	Dakota EXT.Cab	BRK-03	CU70	CU70	CU70	CU70	CU70	CU70	CU70	CU69	CU71
2000-04	Dakota Crew Cab	BRK-07	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU77	CU80
2005-10	Dakota EXT.Cab	BRK-116	CU70	CU70	CU70	CU70	CU70	CU70	CU70	CU69	CU71
2005-10	Dakota Crew Cab	BRK-116	CU80	CU80	CU80	CU80	CU80	CU80	CU80	N/A	CU80
1997-00	Durango	BRK-01	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU77	CU80
2001-03	Durango	BRK-06	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU77	CU80
2004-10	Durango	BRK-93	CU80	CU80	CU80	CU80	CU80	CU80	CU80	N/A	CU80
1995-01	RAM 1500/2500 EXT.Cab 3 & 4 Door	BRK-05	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU77	CU80
1995-01	RAM 1500 STD. Cab	BRK-05S	CU54	N/A	CU54	CU54	CU54	CU54	CU54	N/A	N/A
2002-09	Ram 1500/2500/3500 Quad Cab	BRK-08	CU80	CU80	CU80	CU80	CU80	CU80	CU80	N/A	CU80
2006-09	Mega Cab 2500/3500	BRK-08	CU102	N/A	CU102	CU102	CU102	N/A	N/A	N/A	N/A
2002-08	Ram STD Cab	BRK-08S	CU54	N/A	CU54	CU54	CU54	CU54	CU54	N/A	N/A
2007 -10	Nitro	BRK-129	CU62	N/A	CU62	CU62	CU62	N/A	N/A	N/A	N/A
2009-11	Ram 1500 Quad Cab	BRK-151	CU80	CU80	CU80	CU80	CU80	CU80	CU80	N/A	CU80
2009-11	Ram 1500 Crew Cab	BRK-151	CU86	CU86	CU86	CU86	CU86	CU86	N/A	N/A	N/A



## Vehicle Specific Bracket Kit & Part # Reference

Vehicle Description		Running Board Reference Fitment									
<i>Ford</i>		<b>BRK KIT</b>	<b>MX</b>	<b>E2</b>	<b>SL</b>	<b>PLT</b>	<b>EDGE</b>	<b>UNI</b>	<b>UNI-II</b>	<b>X</b>	<b>X-II</b>
<b>YEAR</b>		<b>C810</b>	<b>C110</b>	<b>C310</b>	<b>C410</b>	<b>C510</b>	<b>C610</b>	<b>C810</b>	<b>C710</b>	<b>C910</b>	<b>C910</b>
2006-10	Explorer 4 door	BRK-122	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU80
2006-10	Explorer Sport trac	BRK-122	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU80
1997-03	F-150 Ext. Cab	BRK-27	CU70	CU70	CU70	CU70	CU70	CU70	CU70	CU70	CU71
2000-03	F-150 Crew Cab	BRK-27	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU84	CU80
1998-11	Super Duty F250/350/550/650 EXT. Cab	BRK-24	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU77	CU80
1998-11	Super Duty F250/350/550/650 Crew Cab	BRK-25	CU90	CU90	CU90	CU90	CU90	CU90	CU90	CU84	N/A
2004-08	F150 Crew Cab	BRK-90	CU86	N/A	CU86	CU86	CU86	CU86	N/A	CU84	N/A
2004-10	F150 EXT. Cab	BRK-91	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU77	CU80
2004-10	F150 STD. Cab	BRK-89	CU54	N/A	CU54	CU54	CU54	CU54	CU54	N/A	N/A
2009-10	F150 Crew Cab	BRK-90	CU90	CU90	CU90	CU90	CU90	CU90	CU90	N/A	CU90
1997-06	Expedition	BRK-21	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU77	CU80
2007-10	Expedition	BRK-127	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU77	CU80
2007-10	Expedition EL	BRK-127	CU90	CU90	CU90	CU90	CU90	CU90	CU90	N/A	CU90
1991-01	Explorer (No for OE side skirts)	BRK-22	CU70	CU70	CU70	CU70	CU70	CU70	CU70	CU69	CU71
2002-05	Explorer	BRK-33	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU77	CU80
1992-10	E-Series Van	BRK-35	CU102	N/A	CU102	CU102	CU102	N/A	N/A	N/A	N/A
2002-05	Explorer Sport	BRK-34	CU66	N/A	CU66	CU66	CU66	N/A	N/A	N/A	N/A
1998-05	Excursion	BRK-25	CU90	CU90	CU90	CU90	CU90	CU90	CU90	N/A	CU90
<i>GMC</i>		<b>BRK KIT</b>	<b>MX</b>	<b>E2</b>	<b>SL</b>	<b>PLT</b>	<b>EDGE</b>	<b>UNI</b>	<b>UNI-II</b>	<b>X</b>	<b>X-II</b>
<b>YEAR</b>		<b>C810</b>	<b>C110</b>	<b>C310</b>	<b>C410</b>	<b>C510</b>	<b>C610</b>	<b>C810</b>	<b>C710</b>	<b>C910</b>	<b>C910</b>
2004-10	Canyon Crew Cab	BRK-92	CU80	CU80	CU80	CU80	CU80	CU80	CU80	N/A	CU80
2004-10	Canyon EXT. Cab	BRK-92	CU70	CU70	CU70	CU70	CU70	CU70	CU70	N/A	CU71
2004-10	Canyon STD. Cab	BRK-92S	CU54	N/A	CU54	CU54	CU54	CU54	CU54	CU54	N/A
2001-10	Envoy	BRK-10	CU70	CU70	CU70	CU70	CU70	CU70	CU70	CU77	CU71
2002-07	Envoy XL	BRK-70	CU90	CU90	CU90	CU90	CU90	CU90	CU90	N/A	CU90
2002-09	Envoy XUV	BRK-70	CU90	CU90	CU90	CU90	CU90	CU90	CU90	N/A	CU90
1997-04	Jimmy 4-doors (w/o cladding only)	BRK-14	CU70	CU70	CU70	CU70	CU70	CU70	CU70	CU69	CU71
2002-08	Hummer H2	BRK-85	CU80	CU80	N/A	CU80	CU80	N/A	N/A	N/A	N/A
2006-08	Hummer H3	BRK-150	CU70	CU70	CU70	CU70	CU70	N/A	N/A	N/A	N/A
2000-04	Safari (need to move AC lines)	BRK-20	CU80	CU70	CU70	CU80	CU80	CU80	CU80	N/A	N/A
1988-98	Sierra EXT. Cab 1500/2500	BRK-11	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU77	CU80
1992-99	Sierra Crew Cab (90" board extends into bed)	BRK-15	CU86	CU86	CU86	CU86	CU86	CU86	CU86	N/A	CU90
1999-06	Sierra 1500/2500 EXT.Cab	BRK-16	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU77	CU80
2001-06	Sierra 2500 Crew Cab (90" board extends into bed)	BRK-17	CU86	CU86	CU86	CU86	CU86	CU86	CU90	N/A	CU90



## Vehicle Specific Bracket Kit & Part # Reference

<i>Vehicle Description</i>		<i>Running Board Reference Fitment</i>									
<b>GMC</b>		<b>BRK KIT</b>	<b>MX</b>	<b>E2</b>	<b>SL</b>	<b>PLT</b>	<b>EDGE</b>	<b>UNI</b>	<b>UNI-II</b>	<b>X</b>	<b>X-II</b>
<b>YEAR</b>		<b>C810</b>	<b>C110</b>	<b>C310</b>	<b>C410</b>	<b>C510</b>	<b>C610</b>	<b>C810</b>	<b>C710</b>	<b>C910</b>	<b>C910</b>
2004-06	Sierra 1500 Crew Cab 5'.5" Short Bed	BRK-17A	CU86	CU86	CU86	CU86	CU86	CU86	CU90	N/A	CU90
1999-04	Sierra EXT. Cab	BRK-16	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU77	CU80
2000-06	Sonoma	BRK-14S	CU54	N/A	CU54	CU54	CU54	CU54	CU54	CU54	CU54
1992-99	GMC Suburban	BRK-15	CU90	CU90	CU90	CU90	CU90	CU90	CU90	N/A	CU90
1996-99	Yukon 4-Door	BRK-12	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU77	CU80
1996-99	Yukon 2-Door	BRK-12	CU70	CU70	CU70	CU70	CU70	CU70	CU70	CU77	CU71
2000-04	Yukon 4-Door	BRK-18	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU77	CU80
2005-10	Yukon 4-Door	BRK-119	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU77	CU80
2000-04	Yukon XL	BRK-18	CU90	CU90	CU90	CU90	CU90	CU90	CU90	N/A	CU90
2005-10	Yukon XL	BRK-119A	CU90	CU90	CU90	CU90	CU90	CU90	CU90	N/A	CU90
2007-10	Sierra Crew Cab (90" board extends into bed)	BRK-126	CU86	N/A	CU86	CU86	CU86	CU86	N/A	N/A	N/A
2007-10	Sierra STD. Cab	BRK-130	CU54	N/A	CU54	CU54	CU54	CU54	CU54	CU54	N/A
2007-10	Sierra EXT. Cab	BRK-130	CU80	CU80	CU80	CU80	CU80	CU80	CU80	N/A	CU80
<b>Jeep</b>		<b>BRK KIT</b>	<b>MX</b>	<b>E2</b>	<b>SL</b>	<b>PLT</b>	<b>EDGE</b>	<b>UNI</b>	<b>UNI-II</b>	<b>X</b>	<b>X-II</b>
<b>YEAR</b>		<b>C810</b>	<b>C110</b>	<b>C310</b>	<b>C410</b>	<b>C510</b>	<b>C610</b>	<b>C810</b>	<b>C710</b>	<b>C910</b>	<b>C910</b>
1994-98	Cherokee	BRK-30	CU70	CU70	CU70	CU70	CU70	CU70	CU70	CU69	CU71
2005-07	Grand Cherokee	BRK-74	CU70	CU70	CU70	CU70	CU70	CU70	CU70	CU70	CU71
2000-07	Liberty	BRK-56	CU67	N/A	CU67	CU67	CU67	N/A	N/A	NA	N/A
2008-10	Liberty	BRK-129	CU62	N/A	CU62	CU62	CU62	N/A	N/A	N/A	N/A
2006-10	Commander	BRK-123	CU70	CU70	CU70	CU70	CU70	CU70	CU70	CU69	CU70
<b>Honda</b>		<b>BRK KIT</b>	<b>MX</b>	<b>E2</b>	<b>SL</b>	<b>PLT</b>	<b>EDGE</b>	<b>UNI</b>	<b>UNI-II</b>	<b>X</b>	<b>X-II</b>
<b>YEAR</b>		<b>C810</b>	<b>C110</b>	<b>C310</b>	<b>C410</b>	<b>C510</b>	<b>C610</b>	<b>C810</b>	<b>C710</b>	<b>C910</b>	<b>C910</b>
2000-02	Passport	BRK-52	CU70	CU70	CU70	CU70	CU70	CU70	CU70	CU69	N/A
2008-10	CR-V	BRK-131	CU70	CU70	CU70	CU70	CU70	CU70	CU70	CU69	N/A
2002-07	CR-V (Need to remove mud flap)	BRK-80	CU70	CU70	CU70	CU70	CU70	CU69	CU70	CU69	N/A
2002-08	Pilot (Need to remove mud flap)	BRK-81	CU70	CU70	CU70	CU70	CU70	CU69	CU70	CU69	N/A
2009-10	Pilot	BRK-132	CU70	CU70	CU70	CU70	CU70	CU69	CU70	CU69	N/A
2005-10	Ridgeline	BRK-75	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU84	CU80
<b>Hyundai</b>		<b>BRK KIT</b>	<b>MX</b>	<b>E2</b>	<b>SL</b>	<b>PLT</b>	<b>EDGE</b>	<b>UNI</b>	<b>UNI-II</b>	<b>X</b>	<b>X-II</b>
<b>YEAR</b>		<b>C810</b>	<b>C110</b>	<b>C310</b>	<b>C410</b>	<b>C510</b>	<b>C610</b>	<b>C810</b>	<b>C710</b>	<b>C910</b>	<b>C910</b>
2001-06	Santa Fe	BRK-54	CU70	N/A	CU70	CU70	CU70	CU69	N/A	CU69	N/A
2007-10	Santa Fe	BRK-135	CU70	CU70	CU70	CU70	CU70	N/A	N/A	N/A	N/A



## Vehicle Specific Bracket Kit & Part # Reference

Vehicle Description		Running Board Reference Fitment									
<b>Hyundai</b>		<b>BRK KIT</b>	<b>MX</b>	<b>E2</b>	<b>SL</b>	<b>PLT</b>	<b>EDGE</b>	<b>UNI</b>	<b>UNI-II</b>	<b>X</b>	<b>X-II</b>
<b>YEAR</b>		<b>C810</b>	<b>C110</b>	<b>C310</b>	<b>C410</b>	<b>C510</b>	<b>C610</b>	<b>C810</b>	<b>C710</b>	<b>C910</b>	<b>C910</b>
2011	Santa Fe	TBA	CU70	CU70	CU70	CU70	CU70	CU70	CU70	N/A	N/A
<b>Infiniti</b>		<b>BRK KIT</b>	<b>MX</b>	<b>E2</b>	<b>SL</b>	<b>PLT</b>	<b>EDGE</b>	<b>UNI</b>	<b>UNI-II</b>	<b>X</b>	<b>X-II</b>
<b>YEAR</b>		<b>C810</b>	<b>C110</b>	<b>C310</b>	<b>C410</b>	<b>C510</b>	<b>C610</b>	<b>C810</b>	<b>C710</b>	<b>C910</b>	<b>C910</b>
2004-07	FX	BRK-83	CU70	CU70	CU70	CU70	CU70	CU70	CU70	N/A	CU71
2004-07	QX 56	BRK-88	CU80	CU80	CU80	CU80	CU80	N/A	N/A	N/A	CU80
<b>Isuzu</b>		<b>BRK KIT</b>	<b>MX</b>	<b>E2</b>	<b>SL</b>	<b>PLT</b>	<b>EDGE</b>	<b>UNI</b>	<b>UNI-II</b>	<b>X</b>	<b>X-II</b>
<b>YEAR</b>		<b>C810</b>	<b>C110</b>	<b>C310</b>	<b>C410</b>	<b>C510</b>	<b>C610</b>	<b>C810</b>	<b>C710</b>	<b>C910</b>	<b>C910</b>
2001-04	Rodeo	BRK-52	CU70	CU70	CU70	CU70	CU70	CU70	CU70	CU69	CU70
2003-08	Ascender EXT	BRK-70	CU90	CU90	CU90	CU90	CU90	CU90	CU90	N/A	CU90
2004-10	Ascender	BRK-10	CU70	CU70	CU70	CU70	CU70	CU70	CU70	CU77	CU70
2006-10	I-350 Crew Cab	BRK-92	CU80	CU80	CU80	CU80	CU80	CU80	CU80	N/A	CU80
2006-10	I-280 EXT. Cab	BRK-92	CU70	CU70	CU70	CU70	CU70	CU70	CU70	N/A	CU71
<b>Kia</b>		<b>BRK KIT</b>	<b>MX</b>	<b>E2</b>	<b>SL</b>	<b>PLT</b>	<b>EDGE</b>	<b>UNI</b>	<b>UNI-II</b>	<b>X</b>	<b>X-II</b>
<b>YEAR</b>		<b>C810</b>	<b>C110</b>	<b>C310</b>	<b>C410</b>	<b>C510</b>	<b>C610</b>	<b>C810</b>	<b>C710</b>	<b>C910</b>	<b>C910</b>
2001-04	Sportage	BRK-61	CU70	CU70	CU70	CU70	CU70	CU69	CU70	CU69	N/A
2011	Sorento	<b>**NEW APPLICATION**</b>	BRK-165	CU70	CU70	CU70	CU70	CU70	CU70	N/A	N/A
2004-05	Sorento	BRK-64	CU70	CU70	CU70	CU70	CU70	CU70	CU70	N/A	N/A
<b>Lincoln</b>		<b>BRK KIT</b>	<b>MX</b>	<b>E2</b>	<b>SL</b>	<b>PLT</b>	<b>EDGE</b>	<b>UNI</b>	<b>UNI-II</b>	<b>X</b>	<b>X-II</b>
<b>YEAR</b>		<b>C810</b>	<b>C110</b>	<b>C310</b>	<b>C410</b>	<b>C510</b>	<b>C610</b>	<b>C810</b>	<b>C710</b>	<b>C910</b>	<b>C910</b>
2000-01	Blackwood	BRK-27	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU84	N/A
2006-10	Mark LT	BRK-90	CU86	CU86	CU86	CU86	CU86	CU86	N/A	N/A	N/A
<b>Mitsubishi</b>		<b>BRK KIT</b>	<b>MX</b>	<b>E2</b>	<b>SL</b>	<b>PLT</b>	<b>EDGE</b>	<b>UNI</b>	<b>UNI-II</b>	<b>X</b>	<b>X-II</b>
<b>YEAR</b>		<b>C810</b>	<b>C110</b>	<b>C310</b>	<b>C410</b>	<b>C510</b>	<b>C610</b>	<b>C810</b>	<b>C710</b>	<b>C910</b>	<b>C910</b>
2004-07	Outlander	BRK-95	CU70	CU70	CU70	CU70	CU70	N/A	N/A	N/A	CU71
2005-08	Raider Crew Cab	BRK-116	CU80	CU80	CU80	CU80	CU80	CU80	CU80	N/A	CU80
2005-08	Raider EXT. Cab	BRK-116	CU70	CU70	CU70	CU70	CU70	CU70	CU70	N/A	CU71
<b>Mercury</b>		<b>BRK KIT</b>	<b>MX</b>	<b>E2</b>	<b>SL</b>	<b>PLT</b>	<b>EDGE</b>	<b>UNI</b>	<b>UNI-II</b>	<b>X</b>	<b>X-II</b>
<b>YEAR</b>		<b>C810</b>	<b>C110</b>	<b>C310</b>	<b>C410</b>	<b>C510</b>	<b>C610</b>	<b>C810</b>	<b>C710</b>	<b>C910</b>	<b>C910</b>
2001-05	Mountaineer	BRK-33	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU77	CU80
2006-10	Mountaineer	BRK-122	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU77	CU80



## Vehicle Specific Bracket Kit & Part # Reference

<i>Vehicle Description</i>		<i>Running Board Reference Fitment</i>									
<b>Nissan</b>		<b>BRK KIT</b>	<b>MX</b>	<b>E2</b>	<b>SL</b>	<b>PLT</b>	<b>EDGE</b>	<b>UNI</b>	<b>UNI-II</b>	<b>X</b>	<b>X-II</b>
<b>YEAR</b>		<b>C810</b>	<b>C110</b>	<b>C310</b>	<b>C410</b>	<b>C510</b>	<b>C610</b>	<b>C810</b>	<b>C710</b>	<b>C910</b>	<b>C910</b>
2002-07	Murano	BRK-83	CU70	CU70	CU70	CU70	CU70	CU70	CU70	CU69	CU71
2004-10	Titan Crew Cab	BRK-88	CU80	CU80	CU80	CU80	CU80	CU80	CU80	N/A	CU80
2004-10	Titan King Cab	BRK-88	CU70	CU70	CU70	CU70	CU70	CU70	CU70	N/A	CU71
2004-10	Armada	BRK-88	CU80	CU80	CU80	CU80	CU80	CU80	CU80	N/A	CU80
2005-10	Pathfinder	BRK-102	CU70	CU70	CU70	CU70	CU70	N/A	N/A	N/A	N/A
2005-10	Frontier Crew Cab	BRK-102	CU77	N/A	CU77	CU77	CU77	N/A	N/A	CU77	N/A
2005-10	Frontier EXT. Cab	BRK-102	CU64	N/A	CU64	CU64	CU64	N/A	N/A	N/A	N/A
2005-10	Xterra (4) door ONLY	BRK-102	CU65	N/A	CU65	CU65	CU65	N/A	N/A	N/A	N/A
2004-09	Quest Van	BRK-121	CU86	CU86	CU86	CU86	CU86	N/A	N/A	N/A	N/A
<b>Oldsmobile</b>		<b>BRK KIT</b>	<b>MX</b>	<b>E2</b>	<b>SL</b>	<b>PLT</b>	<b>EDGE</b>	<b>UNI</b>	<b>UNI-II</b>	<b>X</b>	<b>X-II</b>
<b>YEAR</b>		<b>C810</b>	<b>C110</b>	<b>C310</b>	<b>C410</b>	<b>C510</b>	<b>C610</b>	<b>C810</b>	<b>C710</b>	<b>C910</b>	<b>C910</b>
2002-06	Bravada	BRK-10	CU70	CU70	CU70	CU70	CU70	CU70	CU70	CU77	CU71
<b>Pontiac</b>		<b>BRK KIT</b>	<b>MX</b>	<b>E2</b>	<b>SL</b>	<b>PLT</b>	<b>EDGE</b>	<b>UNI</b>	<b>UNI-II</b>	<b>X</b>	<b>X-II</b>
<b>YEAR</b>		<b>C810</b>	<b>C110</b>	<b>C310</b>	<b>C410</b>	<b>C510</b>	<b>C610</b>	<b>C810</b>	<b>C710</b>	<b>C910</b>	<b>C910</b>
2006-07	Montana SV6 Van	BRK-99	CU86	CU86	CU86	CU86	CU86	CU86	N/A	N/A	N/A
2006-07	Torrent	BRK-62	CU70	CU70	CU70	CU70	CU70	CU70	CU70	N/A	CU71
<b>Saturn</b>		<b>BRK KIT</b>	<b>MX</b>	<b>E2</b>	<b>SL</b>	<b>PLT</b>	<b>EDGE</b>	<b>UNI</b>	<b>UNI-II</b>	<b>X</b>	<b>X-II</b>
<b>YEAR</b>		<b>C810</b>	<b>C110</b>	<b>C310</b>	<b>C410</b>	<b>C510</b>	<b>C610</b>	<b>C810</b>	<b>C710</b>	<b>C910</b>	<b>C910</b>
2002-06	Vue (Unlighted)	BRK-62	CU70	CU70	CU70	CU70	CU70	CU70	CU70	N/A	N/A
2005-06	Relay Van (80" boards in some regions)	BRK-99	CU86	CU86	CU86	CU86	CU86	CU86	N/A	N/A	N/A
<b>Suzuki</b>		<b>BRK KIT</b>	<b>MX</b>	<b>E2</b>	<b>SL</b>	<b>PLT</b>	<b>EDGE</b>	<b>UNI</b>	<b>UNI-II</b>	<b>X</b>	<b>X-II</b>
<b>YEAR</b>		<b>C810</b>	<b>C110</b>	<b>C310</b>	<b>C410</b>	<b>C510</b>	<b>C610</b>	<b>C810</b>	<b>C710</b>	<b>C910</b>	<b>C910</b>
2005-10	Equator Crew Cab	BRK-102	CU77	N/A	CU77	CU77	CU77	N/A	N/A	CU77	N/A
2005-10	Equator EXT. Cab	BRK-102	CU64	N/A	CU64	CU64	CU64	N/A	N/A	N/A	N/A
2005-08	XL7	BRK-62	CU80	CU80	CU80	CU80	CU80	CU80	CU80	N/A	N/A
<b>Toyota</b>		<b>BRK KIT</b>	<b>MX</b>	<b>E2</b>	<b>SL</b>	<b>PLT</b>	<b>EDGE</b>	<b>UNI</b>	<b>UNI-II</b>	<b>X</b>	<b>X-II</b>
<b>YEAR</b>		<b>C810</b>	<b>C110</b>	<b>C310</b>	<b>C410</b>	<b>C510</b>	<b>C610</b>	<b>C810</b>	<b>C710</b>	<b>C910</b>	<b>C910</b>
2001-07	Highlander	BRK-44	CU70	CU70	CU70	CU70	CU70	CU69	N/A	CU69	N/A
2008-11	Highlander	BRK-140	CU70	CU70	CU70	CU70	CU70	CU70	CU70	N/A	N/A
2004-10	Sienna Van	BRK-96	CU84	N/A	CU84	CU84	CU84	N/A	N/A	N/A	N/A



## Vehicle Specific Bracket Kit & Part # Reference

<i>Vehicle Description</i>		<i>Running Board Reference Fitment</i>									
<b>Toyota</b>		<b>BRK KIT</b>	<b>MX</b>	<b>E2</b>	<b>SL</b>	<b>PLT</b>	<b>EDGE</b>	<b>UNI</b>	<b>UNI-II</b>	<b>X</b>	<b>X-II</b>
<b>YEAR</b>		<b>C810</b>	<b>C110</b>	<b>C310</b>	<b>C410</b>	<b>C510</b>	<b>C610</b>	<b>C810</b>	<b>C710</b>	<b>C910</b>	<b>C910</b>
2003-09	4Runner	BRK-47	CU70	CU70	CU70	CU70	CU70	CU69	CU70	CU69	N/A
2010-11	4Runner Trail/ SR5 4cyl	BRK-47	CU70	CU70	CU70	CU70	CU70	CU69	CU70	CU69	N/A
2010-11	4Runner Limited/ SR5 6 cyl	BRK-147	CU70	CU70	CU70	CU70	CU70	CU69	CU70	CU69	N/A
2001-07	Sequoia (Unlighted)	BRK-43	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU77	CU80
2008-10	Sequoia	BRK-145	CU82	CU80	CU82	CU82	CU82	CU80	CU80	N/A	CU80
1999-04	Tacoma Access Cab	BRK-40	CU70	CU70	CU70	CU70	CU70	CU69	CU70	CU69	N/A
1999-04	Tacoma STD.	BRK-40S	CU54	N/A	CU54	CU54	CU54	CU54	CU54	CU54	N/A
2001-04	Tacoma D-Cab	BRK-46	CU80	CU80	CU80	CU80	CU80	CU80	CU80	N/A	CU80
2002-04	Tacoma Access Cab	BRK-46	CU69	CU70	CU69	CU69	CU69	CU69	CU69	CU69	N/A
2002-04	Tacoma STD Cab	BRK-46S	CU54	N/A	CU54	CU54	CU54	CU54	CU54	CU54	N/A
2005-10	Tacoma Access Cab	BRK-100	CU70	CU70	CU70	CU70	CU70	CU70	CU70	N/A	CU71
2005-10	Tacoma D-Cab	BRK-100	CU84	CU80	CU84	CU84	CU84	CU80	CU80	CU84	CU80
2005-10	Tacoma STD Cab	BRK-100	CU54	N/A	CU54	CU54	CU54	CU54	CU54	CU54	N/A
1999-06	Tundra Access Cab	BRK-42	CU70	CU70	CU70	CU70	CU70	CU70	CU70	CU69	N/A
1999-06	Tundra STD.	BRK-42	CU54	N/A	CU54	CU54	CU54	CU54	CU54	CU54	N/A
2004-06	Tundra Crew Cab (Unlighted)	BRK-43	CU80	CU80	CU80	CU80	CU80	CU80	CU80	CU77	CU80
2006-10	RAV-4	BRK-125	CU70	CU70	CU70	CU70	CU70	CU70	CU70	CU70	CU71
2006-10	FJ	BRK-47	CU62	N/A	CU62	CU62	CU62	CU65	N/A	N/A	N/A
2007-10	Tundra Crew Max	BRK-145	CU90	CU90	CU90	CU90	CU90	N/A	CU90	N/A	N/A
2007-10	Tundra D Cab	BRK-145	CU80	CU80	CU80	CU80	CU80	CU80	CU80	N/A	N/A
2007-10	Tundra STD. Cab	BRK-145	CU54	N/A	CU54	CU54	CU54	N/A	N/A	N/A	N/A

<b>Universal Bracket</b>		<b>BRK KIT</b>	<b>MX</b>	<b>E2</b>	<b>SL</b>	<b>PLT</b>	<b>EDGE</b>	<b>UNI</b>	<b>UNI-II</b>	<b>X</b>	<b>X-II</b>
		<b>C810</b>	<b>C110</b>	<b>C310</b>	<b>C410</b>	<b>C510</b>	<b>C610</b>	<b>C810</b>	<b>C710</b>	<b>C910</b>	<b>C910</b>
Universal Bracket to fit most applications		BRK-87	Most of Our Running Boards will work to fit Vehicles								

---

---

---

---

---

---

---

---



## MATRIX SERIES RUNNING BOARD

### RUNNING BOARD PART NUMBER REFERENCE GUIDE

Description	
<b>MATRIX Series Chrome Board Non-lighted</b>	
<b>Part #</b>	
54" Matrix Chrome	C110-CU54P
70" Matrix Chrome	C110-CU70P
80" Matrix Chrome	C110-CU80P
86" Matrix Chrome	C110-CU86P
90" Matrix Chrome	C110-CU90P
102" Matrix Chrome	C110-CU102P
<b>MATRIX Series Silver Anodized Board Non-lighted</b>	
<b>Part #</b>	
54" Matrix Silver Anodized	C110-CU54A
70" Matrix Silver Anodized	C110-CU70A
80" Matrix Silver Anodized	C110-CU80A
86" Matrix Silver Anodized	C110-CU86A
90" Matrix Silver Anodized	C110-CU90A
102" Matrix Silver Anodized	C110-CU102A
<b>MATRIX Series Black Powder Coat Board Non-lighted</b>	
<b>Part #</b>	
54" Matrix Black Powder Coat	C110-CU54B
70" Matrix Black Powder Coat	C110-CU70B
80" Matrix Black Powder Coat	C110-CU80B
86" Matrix Black Powder Coat	C110-CU86B
90" Matrix Black Powder Coat	C110-CU90B
102" Matrix Black Powder Coat	C110-CU102B
<b>MATRIX Series Painted to Match Board Non-lighted</b>	
<b>Part #</b>	
54" Matrix Painted to Match	C110-CU54PTD
70" Matrix Painted to Match	C110-CU70PTD
80" Matrix Painted to Match	C110-CU80PTD
86" Matrix Painted to Match	C110-CU86PTD
90" Matrix Painted to Match	C110-CU90PTD
102" Matrix Painted to Match	C110-CU102PTD



<b><u>E2</u> SERIES RUNNING BOARD</b>	
RUNNING BOARD PART NUMBER REFERENCE GUIDE	
Description	
<b>E2 Series Silver Anodized Board Non-Lighted</b>	
	<b>Part #</b>
70" E2 Silver Anodized	C310-CU70A
80" E2 Silver Anodized	C310-CU80A
86" E2 Silver Anodized	C310-CU86A
90" E2 Silver Anodized	C310-CU90A
<b>E2 Series Black Powder Coat Board Non-Lighted</b>	
	<b>Part #</b>
70" E2 Black Powder Coat	C310-CU70B
80" E2 Black Powder Coat	C310-CU80B
86" E2 Black Powder Coat	C310-CU86B
90" E2 Black Powder Coat	C310-CU90B
<b>E2 Series Chrome Board Non-Lighted</b>	
	<b>Part #</b>
70" E2 Chrome	C310-CU70P
80" E2 Chrome	C310-CU80P
86" E2 Chrome	C310-CU86P
90" E2 Chrome	C310-CU90P
<b><u>PLATINUM</u> SERIES RUNNING BOARD</b>	
RUNNING BOARD PART NUMBER REFERENCE	
Description	
<b>Platinum Series Chrome Board Non-Lighted</b>	
	<b>Part #</b>
54" Platinum Chrome	C510-CU54P
70" Platinum Chrome	C510-CU70P
80" Platinum Chrome	C510-CU80P
86" Platinum Chrome	C510-CU86P
90" Platinum Chrome	C510-CU90P
102" Platinum Chrome	C510-CU102P



<b><u>SL</u> SERIES RUNNING BOARD</b>	
RUNNING BOARD PART NUMBER REFERENCE GUIDE	
Description	
<b>SL Series Silver Anodized Board Non-Lighted</b>	<b>Part #</b>
54" SL Silver Anodized	C410-CU54S
70" SL Silver Anodized	C410-CU70S
80" SL Silver Anodized	C410-CU80S
84" SL Silver Anodized	C410-CU84S
86" SL Silver Anodized	C410-CU86S
90" SL Silver Anodized	C410-CU90S
102" SL Silver Anodized	C410-CU102S
<b>SL Series Painted to Match Board Non-Lighted</b>	<b>Part #</b>
54" SL Painted to Match	C410-CU54PTD
70" SL Painted to Match	C410-CU70PTD
80" SL Painted to Match	C410-CU80PTD
86" SL Painted to Match	C410-CU86PTD
90" SL Painted to Match	C410-CU90PTD
102" SL Painted to Match	C410-CU102PTD
<b><u>UNI 2</u> SERIES RUNNING BOARD</b>	
RUNNING BOARD PART NUMBER REFERENCE GUIDE	
Description	
<b>UNI 2 Series Board Non-Lighted</b>	<b>Part #</b>
54" Universal II.	C710-CU54
70" Universal II.	C710-CU70
80" Universal II.	C710-CU80
90" Universal II.	C710-CU90
<b>UNI 2 Series Board Lighted</b>	<b>Part #</b>
70" Universal II. Lighted	C710-CU70L
80" Universal II. Lighted	C710-CU80L
90" Universal II. Lighted	C710-CU90L
<i>Lights located on the Apron of the Running Board</i>	



## EDGE SERIES RUNNING BOARD

### RUNNING BOARD PART NUMBER REFERENCE GUIDE

#### Description

Edge Series Chrome Board Non-Lighted	Part #
54" Edge Chrome	C610-CU54P
70" Edge Chrome	C610-CU70P
80" Edge Chrome	C610-CU80P
86" Edge Chrome	C610-CU86P
90" Edge Chrome	C610-CU90P
102" Edge Chrome	C610-CU102P
Edge Series Black Powder Coat Board Non-Lighted	Part #
54" Edge Black Powder Coat	C610-CU54B
70" Edge Black Powder Coat	C610-CU70B
80" Edge Black Powder Coat	C610-CU80B
86" Edge Black Powder Coat	C610-CU86B
90" Edge Black Powder coat	C610-CU90B
102" Edge Black Powder Coat	C610-CU102B
Edge Series Silver Anodized Board Non-Lighted	Part #
54" Edge Silver Anodized	C610-CU54S
70" Edge Silver Anodized	C610-CU70S
80" Edge Silver Anodized	C610-CU80S
86" Edge Silver Anodized	C610-CU86S
90" Edge Silver Anodized	C610-CU90S
102" Edge Silver Anodized	C610-CU102S

## GM FACTORY STYLE RUNNING BOARD

### RUNNING BOARD PART NUMBER REFERENCE GUIDE

#### Description

GMC/Chevrolet Factory Style Series Board Non-Lighted	Part #
90" Factory	C795-517
80" Factory	C795-518



## UNI 1 SERIES RUNNING BOARD

### RUNNING BOARD PART NUMBER REFERENCE GUIDE

#### Description

UNI 1. Series Board Non-Lighted	Part #
54" Universal I.	C810-CU54
69" Universal I.	C810-CU69
70" Universal I.	C810-CU70
80" Universal I.	C810-CU80
86" Universal I.	C810-CU86
90" Universal I.	C810-CU90

UNI 1. Series Board Lighted	Part #
65" Universal I. Lighted	C810-CU65L
69" Universal I. Lighted	C810-CU69L
70" Universal I. Lighted	C810-CU70L
80" Universal I. Lighted	C810-CU80L
86" Universal I. Lighted	C810-CU86L
90" Universal I. Lighted	C810-CU90L

### *Toyota Packages*

*Packages include boards, brackets, hardware in one box*

<b>2005+ Tacoma D-Cab</b>	Silver SL boards w/ brackets	C610-500
<b>2005+ Tacoma Access Cab</b>	Silver SL boards w/ brackets	C610-505
<b>2010+ 4Runner (Limited/ SR5 6cyl only)</b>	Chrome Matrix boards w/ brackets	C610-510
<b>2008+ Highlander</b>	Silver SL boards w/ brackets	C610-515
<b>2004-10 Sienna</b>	Silver SL boards w/ brackets	C610-520
<b>2006+ FJ Crusier</b>	Lighted Uni I w/ brackets	C810-CU65L-FJ
<b>*PACKAGES CANNOT BE SUBSTITUTED WITH ANY OTHER</b>		
<b>FINISH, VEHICLE, BOARD, ETC.*</b>		



## X-TREME SERIES RUNNING BOARDS

### RUNNING BOARD PART NUMBER REFERENCE GUIDE & PRICING

Description	
X-Treme Series Painted to Match Board Non-Lighted	Part #
69" X-Treme I. Painted to Matchh	C910-CU69
71" X-Treme II. Painted to Match	C910-CU71
77" X-Treme I. Painted to Match	C910-CU77
80" X-Treme II. Painted to Match	C910-CU80
84" X-Treme I. Painted to Match	C910-CU84
93" X-Treme II. Painted to Match	C910-CU90
X-Treme Series Painted to Match Board Lighted	Part #
54" X-Treme I. Painted to Match Lighted	C910-CU54L
69" X-Treme I. Painted to Match Lighted	C910-CU69L
71" X-Treme II. Painted to Match Lighted	C910-CU71L
77" X-Treme I. Painted to Match Lighted	C910-CU77L
80" X-Treme II. Painted to Match Lighted	C910-CU80L
84" X-Treme I. Painted to Match Lighted	C910-CU84L
93" X-Treme II. Painted to Match Lighted	C910-CU90L

Lights are located on the apron of the running boards

## PAINTED TO MATCH CUSTOM RUNNING BOARDS

ALL CUSTOM BOARDS INCLUDE MOUNTING BRACKETS & HARDWARE

Description	
Lexus Custom Series Running Board Non-lighted	Part #
2006-09 RX-330 RX-350 RX-400	C795-630
Toyota Custom Series Running Board Lighted	Part #
2001-07 Highlander	C910-CU69L-HIGH
2005-09 Tacoma D-Cab	A795-504
2004-06 Tundra D-Cab	A795-501
2001-07 Sequoia	C910-CU84L-SEQ

## PAINTED TO MATCH TRUCK & SUV LOWER FRONT VALANCE

ATS DESIGN OFFERS LIGHTS TO FIT MOST OF THE FRONT VALANCES

Description	
Chevrolet	Part #
1999-02 Silverado EXT. Cab	C795-506
1999-04 Suburban/Tahoe	C795-506
Ford	Part #
2000-03 F150 Super Crew	C795-801
2004 F150 Heritage Edition	C795-801
2004-06 F150	A795-850



**PAINTED TO MATCH FENDER FLARES TRUCK & SUV**

ALL FENDER FLARE APP'S WILL FIT THE **STD CAB**, **EXT CAB**, **CREW CAB**.

Description		
YEAR	Chevrolet	Part #
1999-06	Silverado	C795-505
2007-10	Silverado (5.5 BED)	A795-886
2007-10	Silverado (6.8 & 8.0 BED)	A795-930
2007-10	Suburban	A795-887
2007-10	Tahoe (Will not work on LTZ model)	A795-885
2000-06	Tahoe	C795-505TH
YEAR	Dodge	Part #
2002-05	Ram Short Bed	C795-558
2002-05	Ram Long Bed	A795-860
2006-08	Mega Ram	A795-865
2006-08	Ram Short Bed	A795-865
2006-08	Ram Long Bed	A795-866
YEAR	Ford	Part #
2004-08	F-150	A795-847
1999-07	F-250/F-350	C795-814
2008-10	F-250/F-350	A795-858
1999-07	F-250/F-350 (Off- Road Series 2.25" wheel coverage)	A795-855
2008-10	F-250/F-350 (Off- Road Series 2.25" wheel coverage)	A795-859
1997-03	F-150	C795-805
2000-03	F-150 Super Crew	C795-842
YEAR	GMC	Part #
1999-06	Sierra	C795-505
2000-06	Yukon	A795-880
2007-10	Yukon	A795-885
YEAR	Jeep	Part #
1997-06	TJ / Wrangler	A795-890
YEAR	Nissan	Part #
2005-10	Titan	A795-872
2005-10	Titan (w/ Tool Box Bed Only)	A795-874
YEAR	Toyota	Part #
2007-11	Toyota Tundra	A795-910

\*MOST FLARES GIVE APROX. 1.5" OF WHEEL COVERAGE\*  
PLEASE CALL FOR AVAILABILITY BEFORE ORDERING



## Replacement Parts/ Accessories

THERE ARE NO DISCOUNTS ON REPLACEMENT PARTS & ACCESSORIES

Description	
	Part #
Element shield underside light cavity cover UNI I boards only	C810-WEA-1
Wire Harness Kit 90" Board	C810-WEA-2
Wire Harness Kit 70" & 80" Board	C810-WEA-3
Set (2) UNI. I. board light lenses	C810-WEA-4
Set (2)UNI. II. board light lenses	C710-WEA-4
UNI. I. board light kit	C810-WEA-5
UNI. II. board light kit	C710-WEA-5
Set (4) running board light bulbs	CRIT002
Apron / rocker panel seal gasket UNI. I & II	C795-841-90
ATS lower valance lights (C795-506)	C795-LIGHTS
Set (8) bracket covers aluminum boards only	C810-BRK-COVERS
Rubber Apron for SL running board	C410-BLACKSPASH
Rubber Apron for Platinum running board	C510-BLACKSPASH
Set (2) SL series replacement caps.	C410-CAPS
Set (2) Matrix series replacement caps.	C110-CAPS
Set (2) Platinum / P11 series replacement caps.	C510-CAPS
Set (2) Edge / E2 series replacement caps.	C610-CAPS
Fender Flare Hardware Kit	F/F-Hardware
Bracket hardware only kit	CALL
Spoiler light bottom mount	C494-550
Spoiler light insert mount	C494-500
X-treme Board Step pad (one side only) specify size to XX	C910-CUXXPAD